

# DENALI™

HMT.01.10400

**SOUNDBOMB HORN MOUNT**

HONDA  
NC700X  
2016 -

### Thank you for choosing DENALI

We know you would rather be riding your bike than wrenching on it, so we go the extra mile to make sure our instructions are clear and as easy to understand as possible. If you have any questions, comments, or suggestions don't hesitate to give our gear experts a call at 401.360.2550 or visit DenaliElectronics.com

### Please Read Before Installing

DENALI products should always be installed by a qualified motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. DENALI takes no responsibility for damages caused by improper installation. **Caution:** When installing electronics it is extremely important to pay close attention to how wires are routed, especially when mounting products to the front fender, front forks, or fairing of your motorcycle. Always be sure to turn the handlebars fully left, fully right, and fully compress the suspension to ensure the wires will not bind and have enough slack for your motorcycle to operate properly.


### Installation Tips

We strongly recommend using medium strength liquid thread locker on all screws, nuts, and bolts. It is also important to ensure that all hardware is tightened to the proper torque specifications as listed in your owner's manual. For included accessory hardware please refer to the default torque specifications provided below. Inspect all hardware after the first 30 miles to ensure proper torque specifications are maintained.

Bolt Size	in-lbs	ft-lbs	Nm
M3	10.0 in-lbs	-	1.0 Nm
M4	23.0 in-lbs	-	2.5 Nm
M5	44.5 in-lbs	3.5 ft-lbs	5.0 Nm
M6	78.0 in-lbs	6.5 ft-lbs	9.0 Nm
M8	-	13.5 ft-lbs	18.0 Nm
M10	-	30.0 ft-lbs	41.0 Nm
M12	-	52.0 ft-lbs	71.0 Nm

### Hardware Sizing Guide

Not sure what size bolt you have? Use this ruler to measure screws, bolts, spacers, etc. Remember, the length of a screw or bolt is measured from the start of the "mounting surface" to the end of the screw, so only include the screw head when measuring countersunk screws.



**FIGURE 1**





Illustration not to scale

### Kit Contents

- (a) Bracket.....Qty 1
- (b) M6x45 ISO 7380.....Qty 2
- (c) M6 Washer DIN 125.....Qty 2
- (d) M6 Crush Washer DIN 7603.....Qty 2

### Tools Required


- 4mm Allen Key
- 8mm Socket
- 13mm Wrench



## Remove The OEM Bolts

**Step One:** Identify and remove the two OEM bolts from the right side engine case.

**Note:** The forward mounting point uses a crush washer. This will be replaced with a new washer (d). The original crush washer should NOT be reused.



## Mounting The Horn

**Step Two:** Attach the SoundBomb horn to the bracket (a) using the hardware included with the horn.

**Step Three:** Use the M6x45 screws (b) and M6 washers (c & d) to attach the bracket (a) to the right side engine case. The crush washer (d) goes on the bolt closest to the front of the motorcycle.

**Note:** Use the included crush washer (d). Do NOT reuse the original crush washer. 